

## English commands for voice control with Alexa

### Shutters:

- Turn / switch on [Shutters]
- Turn / switch off [Shutters]
- Raise the shutters. (steps)

Otherwise it's a must to state the percentage ex:

### Shift up:

- Open the [curtains] by [twenty] percent.
- I need you to open the [curtains] by [twenty] percent.
- Bring up the [blinds] by [twenty] percent.
- Just open the [room name] [window] to [twenty-three].
- Will you please open the [Shutters] to [twenty]?
- open the [window] in the [room name] to [fifty].
- Raise the [room name] [blinds] to [fifty] percent closed.

### Shift down:

- Leave the [shutters] in the [room name] at [five] percent closed.
- Shut to [fifty] value the [shutters] in the [room name].
- Adjust the [shutters] found in the [office] to [ten] percent closed please.
- Please shift the [room name] [curtains] to [ten] percent closed please.
- I'd like the [blinds] in the [entrance] to go down to [fifty] percent
- Lower the [window] by [twenty] percent.
- Drop the [curtains] by [40] percent.

### Lights:

#### Turn on:

- Lighten the [ceiling]. (Dim by steps)
- Need [ceiling] on
- Turn on [wall]
- Switch on the [ceiling]
- Let there be light
- Make sure the [living room] lights are turned on
- Power on the [wall] [lamp] in the [toilet room]

**Turn off:**

- Turn of the [lights] in [kitchen] and in [bedroom]
- Switch off [bedroom] [ceiling]
- Power off the [studio] [floor]
- Lights off
- Lights out
- No more light

**Dimming:**

- Lighten the [ceiling].
- Dim the [bedroom] [spot]
- Decrease the [spot]
- Less brightness in the [attic]
- I want the [bedroom] to be less bright
- Brighten [bedroom] [spot]
- Increase [bedroom] [spot]
- 

**Scenes:**

- Activate the [scene] in the [bedroom]
- Turn on (Scene)
- (Scene) on/off